

XFLO | Water Filter

INSTALL INSTRUCTIONS

I. Compression Hose (existing - in House)

1. Turn off home water at the valve - Under Sink.
2. Remove existing $\frac{3}{8}$ " Compression Hose from lower valve under sink. Attach to narrowest end of water filter.
3. *Do not allow Brass Connectors to rotate. May be ok to Use 1 set pliers to grip brass connector, and another set pliers to grip Compression Hose connector. Do not overtighten.
4. Refer IONEXX.COM/XFLO.HTML, Instructions link for Video for visual - if required.

II. Compression Hose (Secondary)

1. Install at the widest end of water filter.
2. Hand tighten hose onto Brass connector plus 1/4 turn with wrench.
3. *Do not allow Brass Connectors to rotate. May be ok to Use 1 set pliers to grip brass connector, and another set pliers to grip Compression Hose connector. Do not overtighten.
4. Install final $\frac{3}{8}$ " compression hose-end onto home water valve.

III. Verify Installation

1. Turn water on at the valve.
2. Check for any visible leaks.
3. If leaks occur, redo the installation at source of leak.

WARNING:

When tightening hose(s) to Home or Water Filter, the Brass connectors should NOT be removed. Leak or Damage to filter housing may result, and is not covered by Warranty.

*Not liable for damages due to improper use or installation. Failure to follow instructions Voids Warranty.