

## XFLO | Water Filter

### INSTALL INSTRUCTIONS

#### I. Compression Hose (existing - in House)

1. Turn off home water at the valve - Under Sink.
2. Remove existing  $\frac{3}{8}$ " Compression Hose from lower valve under sink. Attach to narrowest end of water filter.
3. \*Do not allow Brass Connectors to rotate. May be ok to Use 1 set pliers to grip brass connector, and another set pliers to grip Compression Hose connector. Do not overtighten.
4. Refer [IONEXX.COM/XFLO.HTML](http://IONEXX.COM/XFLO.HTML), Instructions link for Video for visual - if required.

#### II. Compression Hose (Secondary)

1. Install at the widest end of water filter.
2. Hand tighten hose onto Brass connector plus 1/4 turn with wrench.
3. \*Do not allow Brass Connectors to rotate. May be ok to Use 1 set pliers to grip brass connector, and another set pliers to grip Compression Hose connector. Do not overtighten.
4. Install final  $\frac{3}{8}$ " compression hose-end onto home water valve.

#### III. Verify Installation

1. Turn water on at the valve.
2. Check for any visible leaks.
3. If leaks occur, redo the installation at source of leak.

#### **WARNING:**

When tightening hose(s) to Home or Water Filter, the Brass connectors should NOT be removed. Leak or Damage to filter housing may result, and is not covered by Warranty.

\*Not liable for damages due to improper use or installation. Failure to follow instructions Voids Warranty.

#### IV. Maintenance

Backwash filter once per year. Uninstall XFLO and reconnect in the reverse position. Let water run for 10 minutes, then reconnect in the original direct.