



## Xome Homebridge

### INSTRUCTIONS

1. **Plug in Ethernet Components:** Ethernet cable from Router to Ethernet Adapter, then Ethernet Adapter to XOME.
2. **Plug in Power Components:** USB cable from XOME to USB Plug, and plug into wall outlet. (*Wait 3 minutes to proceed*).
3. **Homebridge:** In Safari or Chrome browser, type : **xome.local:8581** username/ password: admin/admin, or create own account if prompted.
4. **Add Xome to HomeKit:** Open Apple Home app, Add Accessory, Scan QR code found in Homebridge interface & add to HomeKit.
5. **Install plugins.** Search plugins from menu option. \*Installed Plugins will require plugin account credentials which allow their use in HomeKit. (Ring, Wiz, myQ, etc).
6. **Wireless:** From Homebridge interface, use hamburger menu at top right, choose Terminal. Type in command line: **su root** (Enter), password: **ionexx** (Enter) . Then type **nmtui** (Enter), Activate Wireless connection, choose your home network. *Then Unplug Ethernet components from Instruction 1.*