

Setup

1. **Plug-in XOME** within 20 feet of home wireless Router for setup, and away from any electromagnetic or wireless interference from any other device. ***Then wait a few minutes to proceed.***
2. **Connect to HOMEBRIDGE WIFI SETUP network.** Use a Mac, iPad, or iPhone in the same room as XOME and Router to connect. If network does not show, Unplug and Move Homebridge.
3. **Choose your Home Wireless Network.** Enter your network Credentials.
4. **Login to Homebridge Interface.** Username “admin” , password “admin. If interface does not automatically appear, type **Homebridge.local** or **IP Address** of Homebridge in browser URL. *Windows computer may deny access to .local or IP.
5. **Install Plugins** Installed Plugins will require plugin account credentials which allow their use in Homebridge. (Ring, Wiz, myQ, etc).
6. **Add Homebridge to Apple HomeKit:** Open APPLE HOME App, choose Add Accessory, More Options, Choose Accessory not shown, Enter Code: **xxx-xx-xxx** found in interface from **Homebridge.local** or **IP Address**.

Troubleshoot

1. **Home network or HOMEBRIDGE WIFI SETUP network not displaying** - Wireless interference - **Unplug & Move Homebridge** away from Wireless TVs, Range Extenders, Wireless Hubs, Microwaves, Tablets, Laptops, etc.
2. **Plugins do not display or operate after install**, 1. restart Homebridge by selecting the power button top right of Homebridge interface, 2. enter correct plugin account credentials. 3. Verify plugins appear in Homebridge interface, under Accessories.
3. **Homebridge Wi-Fi Setup network reappears** - enter your WiFi credentials correctly.
4. **Homebridge drops wifi connection** - Interference, move Homebridge within 20 feet of home wireless Router for setup, and away from any electromagnetic or wireless interference from any other device, or **Enter IP Address of Homebridge in browser URL**.
5. **Transfer Homebridge to another network** - Access Homebridge Interface: type **Homebridge.local** or **IP Address** of Homebridge in browser URL, open Terminal from hamburger menu, type **sudo raspi-config**, select System Options, Wireless Lan, Enter SSID and Passphrase.
6. **Homebridge.local is not accessible from browser URL**, enter the **IP Address** of Homebridge, or reboot XOME. Use an Apple product to reach homebridge interface. *Windows OS may present error Host Unreachable. *If using Wireless Mesh routers, place XOME nearest to the Primary router which is wired to the Modem.

***GPIO Headers/Pins** - If you receive XOME with GPIO headers, pins at the top cover, or female pin connector at bottom, please disregard as they are not required for Homebridge.